



## **PRODUCT INFORMATION SHEET**

### **CarPlan PowerBond Universal Mirror Fix**

#### **Description:**

PowerBond Universal Mirror Fix bonds in minutes. It is suitable for use with glass and metal. For bonding rear view mirrors, phone & radio aerials.

#### **Directions For Use:**

##### **Note**

To achieve a satisfactory bond it is essential that the surfaces to be bonded are absolutely clean, dry and free from grease. It may be necessary first to wash the surface and after drying, to clean the surface further using a pad moistened with Methylated Spirit. Failure to ensure completely clean surfaces is the most common cause of product failure. The mirrors or aerials usually comprise separate based and mirror/Aerial units and it is the base that is bonded to the glass. If this is the case it will be easier to handle if you take the unit off the base and make sure that the base is firmly bonded to the glass before re-assembling the unit.

##### **Directions:**

1. Ensure that the glass and mirror/aerial base surfaces to be bonded are clean and dry. (see note above)
2. Trim the activating mesh to the size of the surface to be bonded on the mirror/aerial base.
3. Temporarily locate the mirror/aerial base on the glass and mark on the position on the outside of the glass.
4. Use scissors to cut the cap from the tip of the mirror fix adhesive tube.
5. Apply Mirror Fix adhesive over the whole of the surface of the mirror/aerial base to be bonded.
6. Place the activating mesh over the adhesive making sure that it is fully saturated with adhesive. Use the tip of the activator tube to press the activator mesh into place.
7. Apply mirror/aerial base to the inside of the glass immediately, sandwiching the activator mesh between the base and the glass, in the area previously marked out.
8. Press firmly onto the glass and hold still and firm for at least 1 minute, do not allow the unit to slide.
9. Allow adhesive to set with mirror/aerial base held in place for at least 15 minutes.
10. Invert the cap and use to re-seal the tube.
11. Carefully re-attach the mirror/aerial to the base if appropriate.
12. Remove exterior location marker.

#### **Availability:**

1g Tube

**DISCLAIMER**

This Product Information Sheet does not constitute to any extent a fitness for purpose warranty or a quality specification. It is intended to be indicative only of the general characteristics of the product(s) and may not be relied upon (in whole or in part) in substitution of nor as a supplement to any of the information and/or instructions and/or warnings set out on the product(s) and/or on any packaging and/or in the relevant Safety Data Sheet (which is available on request).

Neither of the publisher of this Product Information Sheet or the product(s) manufacturer accepts liability for the failure of any person to observe and follow the information and/or instructions and/or warnings on the product(s) and/or on any packaging and/or in the relevant Safety Data Sheet.

Any person selecting and using or causing the product(s) to be used for a specific purpose or any third party recommending the product(s) for a specific purpose without in either case first making all appropriate inquiries as to the suitability of the product(s) for the intended purpose does so at his/her/their own risk and no liability is accepted by the publisher or the product(s) manufacturer for any consequent loss, damage or injury, other than such liability as may not (by operation of law) be excluded.

This Product Information Sheet does not apply to the use of the product(s) in any combination or with other products or materials.

Users of a product or products marked "For Professional Use Only" are deemed to declare and acknowledge for themselves professional levels of skill, knowledge, competence and experience in the selection and use of such product(s).

Product Information Sheets are updated from time to time and inquiries should be made on a regular basis to ensure that this is the latest version available.

TETROSYL LIMITED  
BEVIS GREEN WORKS  
WALMERSLEY  
BURY  
BL9 6RE  
0161 764 5981  
0161 797 5899  
info@tetrosyl.com